

Quick Operation Guide



 Long press ⁽¹⁾ button for 3 seconds to turn off the machine.




Place the charging dock with dust box against the wall on a flat ground, insert the power plug into a socket that meets the requirements, and turn on the power. Make sure that there are no obstacles within 1.2 meters in front of the charging dock with dust box and within 0.5 meters on both sides.



How to use

Charge the robot

Press and hold () button for 3 seconds to turn on the robot, and then press 🛞 button to make the robot automatically recharge. The robot will enter the ready-to-work state when fully charged.



- For initial cleaning task, fully charge the robot.
- Before starting the cleaning task, tidy up the wires and items on the ground to avoid cable entanglement and collision in the cleaning process.
- It is recommended that the robot starts cleaning task from the charging dock with dust box
- When the power is insufficient during the cleaning process, the robot will automatically return to the the charging dock with dust box. After the power is sufficient, it will automatically return to the interrupted location to continue cleaning.